

Technical Bulletin 519

121 Dust Seal Insertion Procedure



1. INSTALL THE SEAL

- Remove the clear plastic strip if present and insert the seal, block side first, into the hole.



2. SECURE THE SEAL

- Press the adhesive covered lip of the seal firmly in place against the side of the modular encoder base.

Installation Complete!